

BLAINE FINENESS APPARATUS

EN196-6 ASTM C204; AASHTO T153

Determines fineness of Portland cement in terms of specific surface expressed as total surface area in square centimeters per gram of cement.

SPECIFICATIONS:

- Product Code : BCE-307/1
- Power supply : 220-240V 1 50Hz.
- Weight App. : 6.8 Kg.



AIR-JET SIEVE SHAKER

EN 933-10

Effective single sieve for dry powders, fragile samples or material that can't be wet sieved, Micron air-jet sieve shaker uses 200mm dia. sieve drums, with 2mm to 20µ particle size range. Unit adapts to 75mm diameter electro-formed sieves in 90mm drums for 45µ to 5µ. Timer and vacuum controls allow reproducibility of the results. Filter attachment, micromesh sieve or cyclone collector accessories may be used to recover fines. Includes 200mm cast aluminum sieve drum housing unit, Plexiglas lid, 15W slotted brass air nozzle, 0-15 minute rotary timer switch, 1HP vacuum power system, gauge and 9.5 gal. recoverable capacity, steel filter canister.

SPECIFICATIONS:

- Product Code : BCE-315
- Power supply : 220V 50 Hz
- Weight App. : 50 kg

