

MORTAR VIBRATION MACHINE

BS 4550

The mould is mounted on a vibration platform with excentric mechanism. Used to prepare cement samples at cube moulds. Conforming cube mould dimension is 70.7*70.7*70.7mm.

SPECIFICATIONS:

| | |
|--------------|----------------------|
| Product Code | : BCE-310 |
| Power supply | : 220V 50 Hz |
| Dimension | : 300 x 900 x 500 mm |
| Weight App. | : 80 kg |



JOLTING TABLE

EN 196-1 - EN ISO 679 - BS 3892

Used to compact cement mortar prisms 40x40x160 mm in mould. The apparatus, consists of a table holding the mould, rotating 60 revolutions per minute. Apparatus has a LCD counter, blow number is adjustable and it stops after counting.

SPECIFICATIONS:

| | |
|--------------|-----------------------|
| Product Code | : BCE-309 |
| Power supply | : 220 V 50 Hz. |
| Dimension | : 395 x 1050 x 275 mm |
| Weight App. | : 85 kg |

